

Chainhold Assembly & Installation

ASSEMBLY

- 1. Place bead chain on the bottom groove of the Chainhold base.
- 2. Snap cover onto the base.
- 3. Pull the chain out of the groove.



INSTALLATION

- Pull the Chainhold down until the chain is fully tensioned (plunger will be fully raised).
- 2. Mark screw hole locations.
- 3. Screw device into wall.



ADDITIONAL MOUNTING OPTIONS

- With provided screws, install bracket first with large screws (use Chainhold marked screw hole locations as reference).
- 2. Install Chainhold into bracket with small screws.





